

MGT-320F (V2)

Technical Manual


MightyGPS International. All right reserved, © 2010

MADE IN CANADA



Contents

1. FEATURES.....	3
2. PERFORMANCE.....	4
2.1 Technical Specification	4
3. Mechanical Dimension.....	5
3.1 PCBA Dimension.....	5
3.1.1 Wafer 6-pin connector's pin assignment	5
4. APPROVED NMEA MESSAGE.....	6
4.1 GGA - GPS FIX DATA	6
4.2 GLL - LATITUDE AND LONGITUDE, WITH TIME OF POSITION FIX AND STATUS.....	7
4.3 GSA - GPS DOP AND ACTIVE SATELLITES.....	7
4.4 GSV - GPS SATELLITE IN VIEW	8
4.5 RMC - RECOMMENDED MINIMUM SPECIFIC GPS/TRANSIT DATA.....	8
4.6 VTG - COURSE OVER GROUND AND GROUND SPEED	9
4.7 ZDA TIME AND DATE	9



1. FEATURES

- 48 channels GPS receiver
- SBAS (WAAS, EGNOS) support
- -145dBm acquisition sensitivity
- -159dBm tracking sensitivity
- Hot start < 2 second
- Cold start < 33 second
- Power consumption < 45mA
- 5m CEP accuracy
- RoHS compliance
- Configuration (Baud rate and NMEA output) user selectable and store in memory

MGT-320F (V2)

Fast Acquisition Enhanced Sensitivity 48 Channels GPS Module

The **MGT-320F (V2)** is a compact all-in-one GPS module solution intended for a broad range of Original Equipment Manufacturer (OEM) products, where fast and easy system integration and minimal development risk is required.

The receiver continuously tracks all satellites in view and provides accurate satellite positioning data. The **MGT-320F (V2)** is optimized for applications requiring good performance, low cost, and maximum flexibility; suitable for a wide range of OEM configurations including handhelds, sensors, asset tracking, PDA-centric personal navigation system, and vehicle navigation products.

Its 48 channels provide fast satellite signal acquisition and short startup time. Acquisition sensitivity of -145dBm and tracking sensitivity of -159dBm offer good navigation performance even in urban canyons having limited sky view.

Satellite-based augmentation systems, such as WAAS and EGNOS, are supported to yield improved accuracy.

Both of the LVTTTL-level and RS232-level serial interface are provided on the interface connector. Supply voltage of 3.5V~8.3V is supported.

Users can modify NMEA sentences or Binary code by the extra flash memory.




2. PERFORMANCE

2.1 Technical Specification

Receiver Type	48 parallel channels, L1 C/A code
Accuracy	Position 5m CEP Velocity 0.1m/sec
Startup Time	< 2sec hot start < 29sec warm start < 33sec cold start
Sensitivity	-145dBm acquisition -159dBm tracking
Update Rate	1Hz
Dynamics	4G (39.2m/sec ²)
Operational Limits	Altitude < 18,000m or velocity < 515m/s (COCOM limit, either may be exceeded but not both)
Serial Interface	LVTTTL level and RS-232 level
Protocol	NMEA-0183 V3.01 User selectable: NMEA Message: GPGGA, GPGLL, GPGSA, GPGSV, GPRMC, GPVTG, GPZDA Baud Rate: 4800, 9600, 19200, 38400, 57600, 115200 Default: NMEA output message: GPRMC, GPGGA, GPGSA, GPGSV Baud rate: 4800, 8 N 1
Datum	Default WGS-84 User definable
Interface Connector	One 1.0mm pitch WTB S/R wafer 87213 SMT R/A type connector
Input Voltage	3.5V ~ 8.3V
Power Consumption	< 45mA
Dimension	34 mm L x 34 mm W x 8.6 mm H
Weight:	14g
Operating Temperature	-20°C ~ +60°C
Humidity	5% ~ 95%


3. Mechanical Dimension

3.1 PCBA Dimension



3.1.1 Wafer 6-pin connector's pin assignment

MGT-320F Lateral View





Pin Number	Signal Name	Description
1	Serial Data Out 1	Asynchronous serial output at LVTTTL level, to output NMEA message
2	Serial Data In 1	Asynchronous serial input at LVTTTL level, to input command message
3	Serial Data Out 2	Asynchronous serial output at RS-232 level, to output NMEA message
4	Serial Data In 2	Asynchronous serial input at RS-232 level, to input command message
5	Power	3.5V ~ 8.3V DC input
6	Ground	Power and signal ground

4. APPROVED NMEA MESSAGE

The serial interface protocol is based on the National Marine Electronics Association's NMEA 0183 ASCII interface specification. This standard is fully define in "NMEA 0183, Version 3.01" The standard may be obtained from NMEA, www.nmea.org

4.1 GGA - GPS FIX DATA

Time, position and position-fix related data (number of satellites in use, HDOP, etc.).

Format:

\$GPGGA,<1>,<2>,<3>,<4>,<5>,<6>,<7>,<8>,<9>,M,<10>,M,<11>,<12>,*<13><CR><LF>

Example:

\$GPGGA,104549.04,2447.2038,N,12100.4990,E,1,06,01.7,00078.8,M,0016.3,M,,*5C<CR><LF>

Field	Example	Description
1	104549.04	UTC time in hhmmss.ss format, 000000.00 ~ 235959.99
2	2447.2038	Latitude in ddmm.mmmm format Leading zeros transmitted
3	N	Latitude hemisphere indicator, 'N' = North, 'S' = South
4	12100.4990	Longitude in dddmm.mmmm format Leading zeros transmitted
5	E	Longitude hemisphere indicator, 'E' = East, 'W' = West
6	1	Position fix quality indicator 0: position fix unavailable 1: valid position fix, SPS mode 2: valid position fix, differential GPS mode
7	06	Number of satellites in use, 00 ~ 12
8	01.7	Horizontal dilution of precision, 00.0 ~ 99.9
9	00078.8	Antenna height above/below mean sea level, -9999.9 ~ 17999.9
10	0016.3	Geoidal height, -999.9 ~ 9999.9
11		Age of DGPS data since last valid RTCM transmission in xxx format (seconds) NULL when DGPS not used
12		Differential reference station ID, 0000 ~ 1023 NULL when DGPS not used
13	5C	Checksum

Note: The checksum field starts with a '*' and consists of 2 characters representing a hex number. The checksum is the exclusive OR of all characters between '\$' and '*'.



4.4 GSV - GPS SATELLITE IN VIEW

Number of satellites in view, PRN number, elevation angle, azimuth angle, and C/No. Only up to four satellite details are transmitted per message. Additional satellite in view information is sent in subsequent GSV messages.

Format:

\$GPGSV,<1>,<2>,<3>,<4>,<5>,<6>,<7>,...,<4>,<5>,<6>,<7> *<8><CR><LF>

Example:

\$GPGSV,2,1,08,26,50,016,40,09,50,173,39,21,43,316,38,17,41,144,42*7C<CR><LF>

\$GPGSV,2,2,08,29,38,029,37,10,27,082,32,18,22,309,24,24,09,145,*7B<CR><LF>

Field	Example	Description
1	2	Total number of GSV messages to be transmitted
2	1	Number of current GSV message
3	08	Total number of satellites in view, 00 ~ 12
4	26	Satellite PRN number, GPS: 01 ~ 32, SBAS: 33 ~ 64 (33 = PRN120)
5	50	Satellite elevation number, 00 ~ 90 degrees
6	016	Satellite azimuth angle, 000 ~ 359 degrees
7	40	C/No, 00 ~ 99 dB Null when not tracking
8	7C	Checksum

4.5 RMC - RECOMMENDED MINIMUM SPECIFIC GPS/TRANSIT DATA

Time, date, position, course and speed data.

Format:

\$GPRMC,<1>,<2>,<3>,<4>,<5>,<6>,<7>,<8>,<9>,<10>,<11>,<12>*<13><CR><LF>

Example:

\$GPRMC,104549.04,A,2447.2038,N,12100.4990,E,016.0,221.0,250304,003.3,W,A*22<CR><LF>

Field	Example	Description
1	104549.04	UTC time in hhmmss.ss format, 000000.00 ~ 235959.99
2	A	Status, 'V' = navigation receiver warning, 'A' = valid position
3	2447.2038	Latitude in ddmm.mmmm format Leading zeros transmitted
4	N	Latitude hemisphere indicator, 'N' = North, 'S' = South
5	12100.4990	Longitude in dddmm.mmmm format Leading zeros transmitted
6	E	Longitude hemisphere indicator, 'E' = East, 'W' = West
7	016.0	Speed over ground, 000.0 ~ 999.9 knots
8	221.0	Course over ground, 000.0 ~ 359.9 degrees
9	250304	UTC date of position fix, ddmmyy format
10	003.3	Magnetic variation, 000.0 ~ 180.0 degrees
11	W	Magnetic variation direction, 'E' = East, 'W' = West
12	A	Mode indicator 'N' = Data invalid 'A' = Autonomous 'D' = Differential 'E' = Estimated
13	22	Checksum



4.6 VTG - COURSE OVER GROUND AND GROUND SPEED

Velocity is given as course over ground (COG) and speed over ground (SOG).

Format:

GPVTG,<1>,T,<2>,M,<3>,N,<4>,K,<5>*<6><CR><LF>

Example:

\$GPVTG,221.0,T,224.3,M,016.0,N,0029.6,K,A*1F<CR><LF>

Field	Example	Description
1	221.0	True course over ground, 000.0 ~ 359.9 degrees
2	224.3	Magnetic course over ground, 000.0 ~ 359.9 degrees
3	016.0	Speed over ground, 000.0 ~ 999.9 knots
4	0029.6	Speed over ground, 0000.0 ~ 1800.0 kilometers per hour
5	A	Mode indicator 'N' = Data invalid 'A' = Autonomous 'D' = Differential 'E' = Estimated
6	1F	Checksum

4.7 ZDA TIME AND DATE

Format:

\$GPZDA,<1>,<2>,<3>,<4>,<5>,<6>*<7><CR><LF>

Example:

\$GPZDA,104548.04,25,03,2004,,*6C<CR><LF>

Field	Example	Description
1	104548.04	UTC time in hhmmss.ss format, 000000.00 ~ 235959.99
2	25	UTC time: day (01 ... 31)
3	03	UTC time: month (01 ... 12)
4	2004	UTC time: year (4 digit year)
5		Local zone hour Not being output by the receiver (NULL)
6		Local zone minutes Not being output by the receiver (NULL)
7	6C	Checksum



MightyGPS International

3-1750 The Queensway, Suite 526- Toronto, ON CANADA

TEL 416-712-9168

Email support@MightyGPS.com

Website www.MightyGPS.com

© 2010 MightyGPS International Corp. All rights reserved.

Not to be reproduced in whole or part for any purpose without written permission of MightyGPS International Corp ("MightyGPS") Information provided by MightyGPS is believed to be accurate and reliable. These materials are provided by MightyGPS as a service to its customers and may be used for informational purposes only. MightyGPS assumes no responsibility for errors or omissions in these materials, nor for its use. MightyGPS reserves the right to change specification at any time without notice.

These materials are provided "as is" without warranty of any kind, either expressed or implied, relating to sale and/or use of MightyGPS products including liability or warranties relating to fitness for a particular purpose, consequential or incidental damages, merchantability, or infringement of any patent, copyright or other intellectual property right. MightyGPS further does not warrant the accuracy or completeness of the information, text, graphics or other items contained within these materials. MightyGPS shall not be liable for any special, indirect, incidental, or consequential damages, including without limitation, lost revenues or lost profits, which may result from the use of these materials.

MightyGPS products are not intended for use in medical, life-support devices, or applications involving potential risk of death, personal injury, or severe property damage in case of failure of the product.