


## TECHNICAL SPECIFICATIONS

|                       |   |
|-----------------------|---|
| Receiver Type         | 12 parallel channel, L1 C/A code  |
| Accuracy              | Position 5m CEP<br>Velocity 0.1m/sec  |
| Startup Time          | < 10sec hot start<br>< 35sec warm start<br>< 45sec cold start                                 |
| Signal Reacquisition  | 1s  |
| Sensitivity           | -137dBm acquisition<br>-145dBm tracking   |
| Update Rate           | 1Hz   |
| Dynamics              | 4G (39.2m/sec <sup>2</sup> )  |
| Operational Limits    | Altitude < 18,000m or velocity < 515m/s<br>(COCOM limit, either may be exceeded but not both) |
| Serial Interface      | LVTTTL level and RS-232 level   |
| Protocol              | NMEA-0183 V3.01<br>GPGGA, GPGLL, GPGSA, GPGSV, GPRMC, GPVTG, GPZDA<br>4800 baud, 8, N, 1      |
| Datum                 | Default WGS-84<br>User definable  |
| RF Connector          | MMCX  |
| Interface Connector   | Two 1.0mm pitch WTB S/R wafer 87213 SMT R/A type connector                                    |
| Input Voltage         | 3.3V DC +/-100mV<br>3.8V - 8.0V   |
| Current Consumption   | 90 - 110mA  |
| Dimension             | 43mm L x 42mm W x 13mm H  |
| Weight:               | 24g   |
| Operating Temperature | -40°C - +85°C   |
| Humidity              | 5% - 95%  |



**LS-40CM Lateral View**

## PINOUT DESCRIPTION

### Connector 1

Used for systems that have supply voltage higher than 3.3V, and requires RS-232 level serial output interface.

| Pin Number | Signal Name       | Description  |
|------------|-------------------|--|
| 1          | Serial Data Out 1 | Asynchronous serial output at LVTTTL level, to output NMEA message         |
| 2          | Serial Data In 1  | Asynchronous serial input at LVTTTL level, to input configuration commands |
| 3          | Serial Data Out 2 | Asynchronous serial output at RS-232 level, to output NMEA message         |
| 4          | Serial Data In 2  | Asynchronous serial input at RS-232 level, to input configuration commands |
| 5          | Power 1           | 3.8V – 8.0V DC input   |
| 6          | Ground            | Power and signal ground  |

### Connector 2

Used for systems that have supply voltage of 3.3V, and requires 3.3V LVTTTL serial output interface.

| Pin Number | Signal Name       | Description  |
|------------|-------------------|--|
| 1          | Ground            | Power and signal ground  |
| 2          | Ground            | Power and signal ground  |
| 3          | NC                | No connection  |
| 4          | Serial Data In 1  | Asynchronous serial input at LVTTTL level, to input configuration commands |
| 5          | Serial Data Out 1 | Asynchronous serial output at LVTTTL level, to output NMEA message         |
| 6          | Power 2           | 3.3V DC input  |

## NMEA Messages

The serial interface protocol is based on the National Marine Electronics Association's NMEA 0183 ASCII interface specification. This standard is fully define in "NMEA 0183, Version 3.01" The standard may be obtained from NMEA, [www.nmea.org](http://www.nmea.org)

### GGA - GPS FIX DATA

Time, position and position-fix related data (number of satellites in use, HDOP, etc.).

#### Format:

```
$GPGGA,<1>,<2>,<3>,<4>,<5>,<6>,<7>,<8>,<9>,M,<10>,M,<11>,<12>,*<13><CR><LF>
```

#### Example:

```
$GPGGA,104549.04,2447.2038,N,12100.4990,E,1,06,01.7,00078.8,M,0016.3,M,.,*5C<CR><LF>
```

| Field | Example    | Description  |
|-------|------------|--|
| 1     | 104549.04  | UTC time in hhmmss.ss format, 000000.00 - 235959.99  |
| 2     | 2447.2038  | Latitude in ddm.mmmm format<br>Leading zeros transmitted   |
| 3     | N          | Latitude hemisphere indicator, 'N' = North, 'S' = South  |
| 4     | 12100.4990 | Longitude in dddmm.mmmm format<br>Leading zeros transmitted  |
| 5     | E          | Longitude hemisphere indicator, 'E' = East, 'W' = West   |
| 6     | 1          | Position fix quality indicator<br>0: position fix unavailable<br>1: valid position fix, SPS mode<br>2: valid position fix, differential GPS mode |
| 7     | 06         | Number of satellites in use, 00 - 12   |
| 8     | 01.7       | Horizontal dilution of precision, 00.0 - 99.9  |
| 9     | 00078.8    | Antenna height above/below mean sea level, -9999.9 - 17999.9   |
| 10    | 0016.3     | Geoidal height, -999.9 - 9999.9  |
| 11    |            | Age of DGPS data since last valid RTCM transmission in xxx format (seconds)<br>NULL when DGPS not used   |
| 12    |            | Differential reference station ID, 0000 - 1023<br>NULL when DGPS not used  |
| 13    | 5C         | Checksum   |

**Note:** The checksum field starts with a '\*' and consists of 2 characters representing a hex number. The checksum is the exclusive OR of all characters between '\$' and '\*'.

### GSA - GPS DOP AND ACTIVE SATELLITES

GPS receiver operating mode, satellites used for navigation, and DOP values.

**Format:**

\$GPGSA,<1>,<2>,<3>,<3>,<3>,<3>,<3>,<3>,<3>,<3>,<3>,<3>,<3>,<3>,<4>,<5>,<6>\* <7><CR><LF>

**Example:**

\$GPGSA,A,3,26,21,,,09,17,,,,,10.8,02.1,10.6\*07<CR><LF>

| Field | Example            | Description   |
|-------|--------------------|---|
| 1     | A                  | Mode, 'M' = Manual, 'A' = Automatic                                       |
| 2     | 3                  | Fix type, 1 = not available, 2 = 2D fix, 3 = 3D fix                       |
| 3     | 26,21,,,09,17,,,,, | PRN number, 01 to 32, of satellite used in solution, up to 12 transmitted |
| 4     | 10.8               | Position dilution of precision, 00.0 to 99.9                              |
| 5     | 02.1               | Horizontal dilution of precision, 00.0 to 99.9                            |
| 6     | 10.6               | Vertical dilution of precision, 00.0 to 99.9                              |
| 7     | 07                 | Checksum  |

### GSV - GPS SATELLITE IN VIEW

Number of satellites in view, PRN number, elevation angle, azimuth angle, and C/No. Only up to four satellite details are transmitted per message. Additional satellite in view information is sent in subsequent GSV messages.

**Format:**

\$GPGSV,<1>,<2>,<3>,<4>,<5>,<6>,<7>,...,<4>,<5>,<6>,<7> \* <8><CR><LF>

**Example:**

\$GPGSV,2,1,08,26,50,016,40,09,50,173,39,21,43,316,38,17,41,144,42\*7C<CR><LF>

\$GPGSV,2,2,08,29,38,029,37,10,27,082,32,18,22,309,24,24,09,145,\*7B<CR><LF>

| Field | Example | Description   |
|-------|---------|---|
| 1     | 2       | Total number of GSV messages to be transmitted                  |
| 2     | 1       | Number of current GSV message                                   |
| 3     | 08      | Total number of satellites in view, 00 - 12                     |
| 4     | 26      | Satellite PRN number, GPS: 01 - 32, SBAS: 33 - 64 (33 = PRN120) |
| 5     | 50      | Satellite elevation number, 00 - 90 degrees                     |
| 6     | 016     | Satellite azimuth angle, 000 - 359 degrees                      |
| 7     | 40      | C/No, 00 - 99 dB<br>Null when not tracking                      |
| 8     | 7C      | Checksum  |

## RMC - RECOMMENDED MINIMUM SPECIFIC GPS/TRANSIT DATA

Time, date, position, course and speed data.

### Format:

\$GPRMC,<1>,<2>,<3>,<4>,<5>,<6>,<7>,<8>,<9>,<10>,<11>,<12>\*<13><CR><LF>

### Example:

\$GPRMC,104549.04,A,2447.2038,N,12100.4990,E,016.0,221.0,250304,003.3,W,A\*22<CR><LF>

| Field | Example    | Description   |
|-------|------------|---|
| 1     | 104549.04  | UTC time in hhmmss.ss format, 000000.00 - 235959.99   |
| 2     | A          | Status, 'V' = navigation receiver warning, 'A' = valid position                                   |
| 3     | 2447.2038  | Latitude in dddmm.mmmm format<br>Leading zeros transmitted  |
| 4     | N          | Latitude hemisphere indicator, 'N' = North, 'S' = South   |
| 5     | 12100.4990 | Longitude in dddmm.mmmm format<br>Leading zeros transmitted                                       |
| 6     | E          | Longitude hemisphere indicator, 'E' = East, 'W' = West  |
| 7     | 016.0      | Speed over ground, 000.0 - 999.9 knots  |
| 8     | 221.0      | Course over ground, 000.0 - 359.9 degrees   |
| 9     | 250304     | UTC date of position fix, ddmmyy format   |
| 10    | 003.3      | Magnetic variation, 000.0 - 180.0 degrees   |
| 11    | W          | Magnetic variation direction, 'E' = East, 'W' = West  |
| 12    | A          | Mode indicator<br>'N' = Data invalid<br>'A' = Autonomous<br>'D' = Differential<br>'E' = Estimated |
| 13    | 22         | Checksum  |

## VTG - COURSE OVER GROUND AND GROUND SPEED

Velocity is given as course over ground (COG) and speed over ground (SOG).

### Format:

GPVTG,<1>,T,<2>,M,<3>,N,<4>,K,<5>\*<6><CR><LF>

### Example:

\$GPVTG,221.0,T,224.3,M,016.0,N,0029.6,K,A\*1F<CR><LF>

| Field | Example | Description   |
|-------|---------|---|
| 1     | 221.0   | True course over ground, 000.0 - 359.9 degrees  |
| 2     | 224.3   | Magnetic course over ground, 000.0 - 359.9 degrees  |
| 3     | 016.0   | Speed over ground, 000.0 - 999.9 knots  |
| 4     | 0029.6  | Speed over ground, 0000.0 - 1800.0 kilometers per hour  |
| 5     | A       | Mode indicator<br>'N' = Data invalid<br>'A' = Autonomous<br>'D' = Differential<br>'E' = Estimated |
| 6     | 1F      | Checksum  |

## ZDA TIME AND DATE

### Format:

\$GPZDA,<1>,<2>,<3>,<4>,<5>,<6>\*<7><CR><LF>

### Example:

\$GPZDA,104548.04,25,03,2004,.,\*6C<CR><LF>


| Field | Example   | Description   |
|-------|-----------|---|
| 1     | 104548.04 | UTC time in hhmmss.ss format, 000000.00 - 235959.99           |
| 2     | 25        | UTC time: day (01 ... 31)                                     |
| 3     | 03        | UTC time: month (01 ... 12)                                   |
| 4     | 2004      | UTC time: year (4 digit year)                                 |
| 5     |           | Local zone hour<br>Not being output by the receiver (NULL)    |
| 6     |           | Local zone minutes<br>Not being output by the receiver (NULL) |
| 7     | 6C        | Checksum  |

## Binary Messages

See *Binary Message Protocol User's Guide* for detailed descriptions.

# MECHANICAL CHARACTERISTICS

*RF Board*



unit : mm

*Digital Board*

